# $EmStat4R^{m}$

POTENTIOSTAT | GALVANOSTAT | IMPEDANCE ANALYZER (optional)



#### **Contents**

Desktop performance in a rugged enclosure	3
Supported Techniques	4
Measurement Specifications	5
System Specifications	6
EmStat4R EIS Accuracy Contour Plot	8
Standard EmStat4R Kit	9
PSTrace: Software for Windows	10
EmStat4R works with MethodSCRIPT™	11
Software Development Kits for .NET	13
PStouch: App for Android	13

> See for more information: www.palmsens.com/es4r



#### Desktop performance in a rugged enclosure

The EmStat4R is a portable USB-powered and wireless Potentiostat, Galvanostat, and optional Frequency Response Analyser (FRA) for Electrochemical Impedance Spectroscopy (EIS). The EmStat4R is great for (sensor) applications that require low currents, from 30 mA down to picoamps, such as sensor applications.



#### Ideal for sensor applications

The Connection Module can be exchanged by the user with a Connection Module suitable for using Screen Printed Electrodes (SPE). This allows for transforming your lab instrument with cell cable to a cable-less solution for use in the field.

Main Specifications	
<ul> <li>potential range</li> </ul>	±3 V
max. compliance voltage	±5 V
<ul> <li>current ranges</li> </ul>	1 nA to 10 mA (8 ranges)
max. current	±30 mA
<ul> <li>electrode connections (SNS module)</li> </ul>	WE, RE, CE, and ground 2 mm banana pins

SPE Connection Module	
sensor pitch	2.54 mm
<ul> <li>electrode connections</li> </ul>	RE, WE, CE
allowed sensor thickness	Between 0.1 mm and 0.8 mm
<ul> <li>maximum sensor width</li> </ul>	11 mm

See section System Specifications on page 6 for more detailed specifications.



#### **Supported Techniques**

The EmStat4R supports the following electrochemical techniques:

#### Voltammetric techniques

•	Linear Sweep Voltammetry	LSV
•	Cyclic Voltammetry	CV
•	Fast Cyclic Voltammetry	FCV
•	AC Voltammetry	ACV

#### Pulsed techniques

Differential Pulse Voltammetry	DPV
Square Wave Voltammetry	SWV
Normal Pulse Voltammetry	NPV

These methods can all be used in their stripping modes which are applied for (ultra-) trace analysis.

#### Amperometric techniques

Chronoamperometry	CA
Zero Resistance Amperometry	ZRA
Chronocoulometry	CC
MultiStep Amperometry	MA
Fast Amperometry	FAM
Pulsed Amperometric Detection	PAD

#### Galvanostatic techniques

Linear Sweep Potentiometry	LSP
Chronopotentiometry	CP
MultiStep Potentiometry	MP
Open Circuit Potentiometry	OCP

#### Other

<ul><li>Mixed Mode</li></ul>	MM
------------------------------	----

Potentiostatic and Galvanostatic
 Impedance spectroscopy
 EIS/GEIS

at fixed frequency or frequency scan vs

- fixed potential or fixed current
- o scanning potential or scanning current
- o time

Fast EIS/GEIS
 Very low interval fixed-frequency measurements

MethodSCRIPT™ allows for developing custom techniques. See page 12 for more information.





# **Measurement Specifications**

The following table shows limits for some technique-specific parameters.

	Parameter	Min	Max
	<ul> <li>Conditioning time</li> </ul>	0	4000 s
All	Deposition time	0	4000 s
techniques (unless	<ul> <li>Equilibration time</li> </ul>	0	4000 s
otherwise specified)	Step potential	LR: 0.100 mV HR: 0.183 mV	250 mV
	<ul> <li>N data points</li> </ul>	3	1 000 000
NPV DPV	Scan rate	LR: 0.1 mV/s (100 µV step) HR: 0.1 mV/s (183 µV step)	1 V/s (5 mV step)
• DPV	Pulse time	0.4 ms	300 ms
- SWV	<ul><li>Frequency</li></ul>	1 Hz	1250 Hz
- LSV - CV	- Scan rate	LR: 0.01 mV/s (100 µV step) HR: 0.01 mV/s (183 µV step)	500 V/s (200 mV step)
	Scan rate	LR: 0.1 mV/s (100 µV step) HR: 0.01 mV/s (183 µV step)	500 V/s (50 mV step)
• FCV	<ul> <li>N averaged scans</li> </ul>	1	65535
	N equil. scans	0	65535
	<ul> <li>Interval time</li> </ul>	50 ms	4294 s
• PAD	<ul> <li>Pulse time</li> </ul>	1 ms	1 s
-1 70	N data points	3	1 000 000 (> 100 days at 10 s interval)
• CA	<ul> <li>Interval time</li> </ul>	0.4 ms	4294 s
• CP • OCP	- Run time	1 ms	> year
	N cycles	1	20000
• MM • MA	■ N levels	1	255
• MP	<ul> <li>Level switching overhead time</li> </ul>	~1 ms (typical)	-
	<ul> <li>Interval time</li> </ul>	0.4 ms	4294 s
	<ul> <li>Interval time</li> </ul>	1 μs	60 s
• FAM	Run time	3 μs	34 days (60 s interval) 50 ms (1 µs interval)
	N data points	3	50000
• Fast EIS	Interval time between points at fixed frequency	~1 ms (typical)	-



# **System Specifications**

General		
dc-potential range	±3 V	
- compliance voltage	±5 V	
maximum current	±30 mA	
- max. data acquisition rate	1M samples/s	
<ul> <li>control loop bandwidth (stability setting)</li> </ul>	320 Hz, 3.2 kHz, 30 kHz or 570 kHz	
- current follower bandwidth	23 Hz in 1 nA and 10 nA range 2.3 kHz in 100 nA and 1 uA range 230 kHz in 10 uA and 100 uA range > 500 kHz in ranges 1 mA and higher	

Potentiostat (controlled potential mode)		
applied potential resolution	100 μV	
- applied potential accuracy	≤ 0.2% ±1 mV offset	
- current ranges	1 nA to 10 mA (8 ranges)	
measured current resolution	0.009% of CR (92 fA on 1 nA range)	
measured current accuracy	< 0.2% of current ±20 pA ±0.2% of range	

Galvanostat (controlled current mode)		
- current ranges	10 nA, 1 uA, 100 uA, 10 mA (4 ranges)	
- applied dc-current	±3 * CR (current range)	
applied dc-current resolution	0.01% of CR	
applied dc-current accuracy	< 0.4% of current ±20 pA ±0.2% of range	
<ul> <li>potential ranges</li> </ul>	50 mV, 100 mV, 200 mV, 500 mv, 1 V	
measured dc-potential resolution	96 μV (1 V) 48 μV (500 mV) 19.2 μV (200 mV) 9.6 μV (100 mV) 4.8 μV (50 mV)	
• measured dc-potential accuracy	$\leq$ 0.2% potential, $\pm 1$ mV offset	

FRA / EIS (impedance measurements)		
frequency range	10 μHz to 200 kHz	
- ac-amplitude range	1 mV to 900 mV rms, or 2.5 V p-p	



GEIS (galvanostatic impedance measurements)	
frequency range	10 μHz to 100 kHz
ac-amplitude range	0.9 * CR A rms


Electrometer	
electrometer amplifier input	$>$ 1 T $\Omega$ // 10 pF
<ul><li>bandwidth</li></ul>	500 kHz

Other	
- communication	USB-C or wireless
• housing	aluminium body only: 11.1 x 6.0 x 2.7 cm with rubber sleeve: 11.8 x 6.8 x 3.3 cm
• weight	~310 g
• power source	USB-C or internal LiPo battery
battery life	Connected wirelessly: ~3 hours with cell @ 10 mA current ~5 hours with cell off
• internal storage space	500 MB, equivalent to >15M datapoints or ~1000 measurement files (whichever comes first)





#### EmStat4R EIS Accuracy Contour Plot



#### Note

The accuracy contour plots were determined with an ac-amplitude of ≤10 mV rms for all limits, except for the high impedance limit, which was determined using an ac-amplitude of 250 mV.

The standard 1 meter cell cables were used. Please note that the true limits of an impedance measurement are influenced by all components in the system, e.g. connections, the environment, and the cell.



#### Standard EmStat4R Kit

A standard EmStat4R kit includes a rugged carrying case with:

- EmStat4R instrument with SNS Connection Module (for use with 1 m cell cable) or SPE Connection Module (for use with Screen Printed Electrodes)
- USB-C cable
- 1 meter cell cable with 2 mm banana pins
- Dummy Cell

#### Optional:

 Optional additional SNS or SPE Connection Module

#### Also included:

- PSTrace software for Windows (on USB drive)
- Manual (hardcopy)
- Quick Start document
- Calibration report









#### **PSTrace: Software for Windows**

PSTrace is designed to get the most out of your instrument right after installation, without going through a long learning period. It has three modes: the Scientific mode which allows you to run all the techniques our instruments have to offer, and two dedicated modes for Corrosion analysis and the Analytical Mode. The Analytical Mode is designed for use with (bio)sensors and allows you to do concentration determinations. Extensive help files and prompts guide the user through a typical analysis.




#### Scripting

The intuitive script editor allows for easily creating a sequence of measurements or other tasks, by means of dragging and dropping actions in a list.







Use the graphical editor to draw the equivalent circuit or enter the CDC directly.

Corrosion mode for Tafel plot analysis and other corrosion data analysis.

#### Other functions in PSTrace

- Concentration determination
- Advanced peak search algorithms
- Open your data in Origin and Excel with one click of a button
- Save all available curves, measurement data and methods to a single file
- Load measurements from the internal storage
- Direct validation of method parameters
- Run custom MethodSCRIPTS™

# Integration with third party software

- Excel
- Origin
- Matlab
- ZView









# | Tafei plot current density | Tafei plot cur

#### Minimum System Requirements

- Windows 7, 8, 10 or 11
- 1 GHz or faster 32-bit (x86) or 64-bit (x64) processor
- 2 GB RAM (32-bit) or 4 GB RAM (64-bit)
- Screen resolution of 1280 x 800 pixels

> See for more information: www.palmsens.com/pstrace



#### EmStat4R works with MethodSCRIPT™

The MethodSCRIPT<sup>TM</sup> scripting language is designed to integrate our instruments and potentiostat (modules) effortlessly in your hardware setup, product, or experiment.

MethodSCRIPT™ gives you full control over your potentiostat. The simple script language is parsed on-board the instrument and allows for running all supported electrochemical techniques, making it easy to combine different measurements and other tasks.

MethodSCRIPT™ can be generated, edited, and executed in PSTrace.

MethodSCRIPT features include:

- Use of variables
- (Nested) loops and conditional logic support
- User code during a measurement iteration
- Exact timing control
- Simple math operations on variables (add, sub, mul, div)
- Digital I/O, for example for waiting for an external trigger
- Logging results to internal storage or external SD card
- Reading auxiliary values like pH or temperature
- and many more...

```
1 e
2 var c
3 var p
4 #Select bandwidth of 40 for 10 points per second
5 set_max_bandwidth 40
6 #Set current range to 1 mA
7 set_range ba 1m
8 #Enable autoranging, between current of 100 uA and 1 mA
9 set_autoranging ba 100u 1m
10 #Turn cell on for measurements
11 cell on
12 #equilibrate at -0.5 V for 5 seconds, using a CA measurement
13 meas_loop_ca p c -500m 500m 5
14 pck_start
15 pck_add p
16 pck_add c
17 pck_end
18 endloop
19 #Start LSV measurement from -0.5 V to 1.5 V, with steps of 10 mV
20 #and a scan rate of 100 mV/s
21 meas_loop_lsv p c -500m 1500m 10m 100m
22 #Send package containing set potential and measured WE current.
23 pck_start
24 pck_add c
25 pck_end
27 #Abort if current exceeds 1200 uA
28 if c > 1200u
29 abort
30 endloop
31 #Turn off cell when done or aborted
32 on_finished:
33 cell_off
34

Online support on MethodSCRIPT
```



Write your own software and integrate (generated) MethodSCRIPTs. No libraries needed.

MethodSCRIPT is parsed on-board the instrument. No DLLs or other type of code libraries are required for using MethodSCRIPT™



Code examples are available for:















> See for more information: www.palmsens.com/methodscript



#### Software Development Kits for .NET

Develop your own application in no time for use with any PalmSens instrument or potentiostat (module). Our SDKs are free of charge.



There are three PalmSens Software Development Kits (SDKs) for .NET. Each SDK can be used with any of our instruments or OEM potentiostat modules to develop your own software. The SDK's come with a set of examples that shows how to use the libraries. PalmSens SDKs with examples are available for the following .NET Frameworks:

- WinForms
- Xamarin (Android)
- WPF

Each SDK comes with code examples for:

- Connecting
- Running measurements and plotting data
- Manual control of the cell
- Accessing and processing measured data
- Analyzing and manipulating data
- Peak detection
- Equivalent Circuit Fitting on impedance data
- Saving and loading files

```
/// <summary>
/// Initializes the EIS method.
/// </summary>
1reference
private void InitMethod()
{
    _methodEIS = new ImpedimetricMethod();
    _methodEIS.ScanType = ImpedimetricMethod.enumScanTy
    _methodEIS.Potential = 0.0f; //0.0V DC potential
    _methodEIS.Eac = 0.01f; //0.01V RMS AC potential at
    _methodEIS.FreqType = ImpedimetricMethod.enumFreque
    _methodEIS.MaxFrequency = 1e5f; //Max frequency is
    _methodEIS.MinFrequency = 10f; //Min frequency is
    _methodEIS.nFrequencies = 11; //Sample at 11 difference
    _methodEIS.EquilibrationTime = 1f; //Equilabrates = 10.00 methodEIS.Ranging.StartCurrentRange = new Current
    _methodEIS.Ranging.MinimumCurrentRange = new Current
    _methodEIS.Ranging.MinimumCurrentRange = new Current
    _methodEIS.Ranging.MaximumCurrentRange = new Current
    _methodEIS.Ranging.Maxim
```

> See for more information: www.palmsens.com/sdk



#### PStouch: App for Android







PStouch is an app for Android devices compatible with all PalmSens, EmStat and Sensit potentiostats. Your smartphone or tablet connects with the EmStat4R via USB

Your smartphone or tablet connects with the EmStat4R via USE or wirelessly.

#### PStouch features:

- Setting up and running measurements
- Loading and saving measured curves
- Analyzing and manipulating peaks
- Sharing measurement data directly via any service like email or Dropbox
- Concentration determination by means of Standard Addition or Calibration Curve
- Support for PalmSens accessories such as a Multiplexer or Stirrer
- All method and curve files are fully compatible with PSTrace software for Windows.

> See for more information: www.palmsens.com/pstouch





Please do not hesitate to contact PalmSens for more details: <a href="mailto:info@palmsens.com">info@palmsens.com</a>

PalmSens BV The Netherlands www.palmsens.com

#### **DISCLAIMER**

Changes in specifications and typing errors reserved. Every effort has been made to ensure the accuracy of this document. However, no rights can be claimed by the contents of this document.